



Drawing Title:

# Deck Edge Before Siding

Date: January 1, 2020

System: Fully Adhered

Detail Number: DCS-105

#3 20133 102nd Ave.  
Langley, BC V1M 4B4  
Phone: (604) 513-0416  
Fax: (604) 513-0428

During construction of a new house, the vinyl membrane is adhered to the wall before the siding is installed.

